

# User Manual




# Index

Device manual

App manual


warranty

# Device Manual



# App manual

First download the CoffeeMush app on your store, then create an account. You can also log in as a guest.



Once you are logged in, you have to connect the application to his composter. This will be done by scanning the QR code on the composter. With the app and the composter connected, the home page will appear. From the home page it's possible to access to the box control, information, general statistics, and the camera. And as you can see on the last screen, from the circular icon on the top right, if clicked, it gives the option to disconnect. If clicking on "log out", the application redirects you to the first screen of all.




On the main screen, when clicking on the icons, the following happens:

From the “boxes” option, a screen is reached where it's possible to see how much time is left for the mushrooms to be ready. There is also the option to mark if they have been picked.

From the “information” option, a screen is reached where it's possible to see information about temperature, humidity, CO<sub>2</sub> levels and amount of light. In the case that any of the measurements are out of range, this will be displayed in red, as is the case with the light indicator.

From the “camera” option, by clicking on it, a real-time photo of the dark room of the composter will appear.

Finally, when the information is being loaded, the screen will look as shown in the screen to the right.



The application will also send notifications in case the mushrooms are ready (as shown in the first screen); and also in case it is necessary to regulate any condition of the composter, (as can be seen in the second screen).



# Warranty

## Warranty

Thank you for your interest in CoffeeMush

What does this limited warranty cover?

This Limited Warranty covers any defects in material or workmanship under normal use during the Warranty Period.

During the Warranty Period, CoffeeMush will repair or replace, at no charge, products or parts of a product that proves defective because of improper material or workmanship, under normal use and maintenance.

How long does the coverage last?

The Warranty Period for Physical Goods purchased from CoffeeMush is 2 years from the date of purchase.

What does this limited warranty not cover?

This Limited Warranty does not cover any problem that is caused by:

Conditions, malfunctions or damage not resulting from defects in material or workmanship

What do you have to do?

To obtain warranty service, you must first contact us to determine the problem and the most appropriate solution for you.

you can contact us at: [coffeemush@gmail.com](mailto:coffeemush@gmail.com)



# CoffeeMush

Brew and renew, from coffee grounds to mushroom bliss!



Email: [coffeemush@gmail.com](mailto:coffeemush@gmail.com)



SCAN ME!

